



## Installation Instructions

**Philmac**  
**VERSA**  
**PHIL**



1 Remove back nut (rubber washer remains) and slide the thread through the appropriate sized hole.



2 Screw the back nut on by hand and then tighten nut using multi-grips or adjustable wrench.



3 Attach the float to the threaded end of lever and tighten the locking nut with multi-grips or adjustable wrench.



5 Where necessary bend the lever to adjust the water level. This can be done by removing the R-pin, sliding out the pivot pin and removing the lever.



6 Using a pair of multi-grips or over a solid surface bend the lever to the necessary angle, then replace the lever.

## Adjusting the water level